


HIGH GLOSS PAINT

care guide



Wipe down using OZ polish cleaner Avoid sharp objects abruptly touching the piece (use felt pads under objects) Do not place HOT objects directly on your piece



Clean up spills immediately using a damp towel — wipe down until completely dry



To touch up small paint chips if they occur— shop local SW/BM stores to locate paint colors
To hire OCC to fix any damages/chips — please email contact@shopoystercreekstudios.com

We love lacquer for its effortless ability to cross between traditional and modern. It works on virtually any style of furniture — and in any décor. Just like any piece of furniture that is painted, scratching and nicking can occur if objects abruptly touch the product. Eating utensils, games, toys, and/or decorative objects such as planters, centerpieces, and trays can scratch your piece if items are not gently used. DO NOT place ay hot object directly on your piece. Clean up spills on the surface immediately.



BURL WOOD

care guide



Wipe down using OZ polish cleaner Do not place HOT objects directly on your piece.



Clean up spills immediately using a damp towel — wipe down until completely dry.



Burl wood is a tree growth in which the grain has grown in a unique manner. No burlwood piece is ever the same!

Burl is commonly found in the form of a rounded outgrowth on a tree trunk or branch that is filled with small knots from dormant buds. Keep in mind that grain patterns will vary from piece to piece adding to the uniqueness of the item.



WHITE OAK + WALNUT

care guide



Wipe down using OZ polish cleaner Do not place HOT objects directly on your piece.



Clean up spills immediately using a damp towel — wipe down until completely dry



Walnut and White Oak is a grainy hardwood. No piece is ever exactly the same! The grain pattern of walnut tends to be more subtle and straight as opposed to oak, which has more prominent swirls.

Please keep in mind that grain patterns will vary from piece to piece adding to the uniqueness of the item. Also, every piece of wood will take the stain finish differently. There could be slight variation in stain finishes from piece to piece.



GRASSCLOTH

care guide



Wipe (Vinyl) Grasscloth with dry cloth to prevent dust accumulations.



To clean spills — Dab spill with a dry paper towel or soft sponge Light stains/blemishes can be removed with a soft brush and soap and water — dry completely.




A performance vinyl grasscloth has the look and feel of a handcrafted, natural material and is virtually seamless.



ACRYLIC

care guide



Clean surface using dishwashing liquid and warm water solution with a microfiber cloth.

Avoid sharp objects abruptly touching the piece (use felt pads under objects)

Do not place HOT objects directly on your piece



Clean up spills immediately using a damp towel — wipe down until completely dry



If scratches occur, use a commercial acrylic cleaner like Novus 7100
Plastic Polish Kit. To hire OCC to fix any damages/chips — please email contact@shopoystercreekstudios.com

Just like any acrylic piece of furniture, scratching and nicking can occur if objects abruptly touch the product. Eating utensils, games, toys, and/or decorative objects such as planters, centerpieces, and trays can scratch your piece if items are not gently used. DO NOT place a hot object directly on your piece. Clean up spills on the surface immediately.